

## **HOW TO ORDER**

Ex1:CHC49UQQQQQ 3 5 9 5 5 0 0 0 M 7 4 В Ex2:CJ U - 2 X 6 Q Q Q 3 2 7 8 0 В 0 K 6 0 0 0

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23

## **SERIES**

HC49U = CHC49UQQQQQ HC49T = CHC49TQQQQQ HC49S = CHC49SQQQQQ HC49SS =CHC49SSQQQQ HC49SM =CHC49SMQQQQ HC49SSM =CHC49SSMQQQ UM1 =CUM1QQQQQQQ

JU-2X6 =CJU-2X6QQQQ JU-3X8 =CJU-3X8QQQQ

UM5 = CUM5QQQQQQQ

AT-3X9 = CAT-3X9QQQQ SMD8045 =CSMD8045QQQ SMD7050 =CSMD7050QQQ

SMD6035 =CSMD6035QQQ COF145T5 =CCOF145T5QQ COF145C5 =CCOF145C5QQ

COF145C3 =CCOF145C3QQ COH146T5 = CCOH146T5QQ

COH146C5 = CCOH146C5QQ COH146C3 =CCOH146C3QQ

MO149T5-2G =CMO149T5-2G MO145C5-2G = CMO145C5-2G

MO145C3-2G = CMO145C3-2G MVC =CMVCQQQQQQQ VC100 =CVC100QQQQQ

VC200 = CVC200QQQQQ TC100 =CTC100QQQQQ

TC200 =CTC200QQQQQ

=CMTCQQQQQQQ MTC

KX327S = CKX327SQQQQ KX327ST =CKX327STQQQ

KX327XS = CKX327XSQQQ

=CKX327XSTQQ KX327XST

KX327E = CKX327EQQQQ

KX327ET = CKX327ETQQQ

KXMC = CKXMCQQQQQ

KXMCT = CKXMCTQQQQQ KXMCE = CKXMCEQQQQQ

KX9A = CKX9AQQQQQQ

KX9AT = CKX9ATQQQQQ

KX9AE = CKX9AEQQQQ KX9B = CKX9BQQQQQQ

KX9BT =CKX9BTQQQQQ

KX9BE = CKX9BEQQQQ

KX7 = CKX7QQQQQQQ

KX7T = CKX7TQQQQQQ

KX7E = CKX7EQQQQQQ

SAW70M = CSAW70MQQQQ SAW115M = CSAW115MQQQ

SAW140M = CSAW140MQQQ

SAW130M4 = CSAW130M4QQ

SAW830M = CSAW830MQQQ

SAW42M24 = CSAW42M24QQ

SAW90M = CSAW90MQQQQ

ZTAMT =CZTAMTQQQQQ

ZTAMX =CZTAMXQQQQQ

ZTTMT =CZTTMTQQQQQ

ZTTMX =CZTTMXQQQQQ

ZTB =CZTBQQQQQQQ

SFU450B = CSFU450BQQQ SFU455B =CSFU455BQQQ

**ZTAC** =CZTACQQQQQQ

=CZTTCQQQQQQ ZTTC

LT10M7A5 =CLT10M7A5QQ

LT10M7S2 =CLT10M7S2QQ LT10M7JA10 =CLT10M7JA10

LT4M5B = CLT4M5BQQQQ

LT5M5B = CLT5M5BQQQQ

LT6M0B = CLT6M0BQQQQ

LT6M5B = CLT6M5BQQQQ

XT4M5B = CXT4M5BQQQQ

XT5M5B

=CXT5M5BQQQQ XT6M0B =CXT6M0BQQQQ

XT6M5B = CXT6M5BQQQQ

## **PACKAGE**

B=BULK

T=5.0mm TAPING AMMO R=5.0mm TAPING REEL A=2.5mmTAPING AMMO

## **FREQUENCY**

	$K \square \square \square \square$	Hz
	$M \square \square \square \square$	Hz